




Nokia Lumia 620 Loudspeaker Replacement

How to disassemble the phone and replace the Loudspeaker / Buzzer / Ringer.

Written By: ZFix



INTRODUCTION

How to disassemble the phone and replace the Loudspeaker / Buzzer / Ringer.



TOOLS:


- [T4 Torx Screwdriver](#) (1)



PARTS:

- [Nokia Lumia 500 610 620 720 820 920 925](#) (1)

Step 1 — Loudspeaker



- Switch off the phone, remove the battery and SIM (Memory) card.
- The lower back cover is held by 3x T4 Torx screws.

⚠ The screws are of two types!

Step 2



- The Loudspeaker is on the lower back cover.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-13 02:26:24 PM.